


# HYDRAULIK-ZYLINDER

Type: LAF10005 | LAF10010 | LAF10015  
LAF10020 | LAF10025 | LAF10030



Ersatzteilliste

	LAF10005	LAF10010	LAF10015	LAF10020	LAF10025	LAF10030
	JR.LAF100A*	JR.LAF100A*	JR.LAF100A*	JR.LAF100A*	JR.LAF100A*	JR.LAF100A*
1	52E0364	52E0372	52E0375	52E0413	52E0403	52E0432
2	53E0446	53E0454	53E0457	53E0489	53E0481	53E0506
3	55E0147	55E0147	55E0147	55E0147	55E0147	55E0147
4	56D0005	56D0005	56D0005	56D0005	56D0005	56D0005
5	(2) 24F0078	(2) 24F0078	(2) 24F0078	(2) 24F0078	(2) 24F0078	(2) 24F0078
6	13A0352	13A0337	13A0164	13A0428	13A0423	13A0436
7	LK3140	LK3140	LK3140	LK3140	LK3140	LK3140
8	24K0566	24K0566	24K0566	24K0566	24K0566	24K0566
*9	(2) 57B0030	(2) 57B0030	(2) 57B0030	(2) 57B0030	(2) 57B0030	(2) 57B0030
10	14A0116	14A0175	14A0175	14A0175	14A0175	14A0175
11	14A0056	14A0056	14A0056	14A0056	14A0056	14A0056
*12	12B0602	12B0602	12B0602	12B0602	12B0602	12B0602
*13	(2) 58F00169	(2) 58F00169	(2) 58F00169	(2) 58F00169	(2) 58F00169	(2) 58F00169
*14	58F0095	58F0095	58F0095	58F0095	58F0095	58F0095
*15	12H0074	12H0074	12H0074	12H0074	12H0074	12H0074
*16	12A0030	12A0030	12A0030	12A0030	12A0030	12A0030
17	33C0011	33C0011	33C0011	33C0011	33C0011	33C0011
18	(2) 14A0162	(2) 14A0162	(2) 14A0162	(2) 14A0162	(2) 14A0162	(2) 14A0162
*19	58F0159	58F0159	58F0159	58F0159	58F0159	58F0159

Dokumentationsbeauftragter: Andreas Bos  
Stand: 03.2019

BAHCO GmbH & Co. KG  
Martener Hellweg 60  
44379 Dortmund  
Telefon: (0231) 91 72 11-0  
Telefax: (0231) 91 72 11-20  
Internet: www.bahco.de  
E-Mail: info@bahco.de

## Hydraulik-Zylinder - Ersatzteilliste

Type  
LAF10005 | LAF10010 |  
LAF10015 | LAF10020 |  
LAF10025 | LAF10030

**BAHCO**  
DORTMUND